



# Timber frame construction | Flat roof with external roof insulation

Airtightness with the pro clima INTELLO / PLUS vapour control membrane. Taping of membranes to one another with TESCON VANA.

*pro clima ... and the insulation is perfect*



Typical structural situation to illustrate the airtightness and windtightness layers. When carrying out planning and performing installation on site, please observe the currently applicable technical regulations and the relevant pro clima recommendations for applications and installation. (German version: 09/21; international version 02/26).